



JP1 AND JP2 CONFIGURE FOR GPS MODEL
 T = IN FOR TRIPMATE, OUT FOR OTHERS
 N = OUT FOR TRIPMATE, IN FOR OTHERS

JP4 = OUT FOR PROGRAMMING
 JP4 = IN FOR NORMAL OPERATION

| | |
|-----------|--------------------|
| Co: | TAPR, INC. |
| Title: | PIC-E |
| Board: | PIC-E |
| Author: | STEVE BIBLE, N7HPR |
| Date: | 10/13/98 |
| Revision: | A |
| Size: | A |
| Sheet | 1 of 1 |

