

# TAPR Versatile WSPR Bias Current Adjustment

The VW's are shipped as a kit. This requires the user to adjust the bias current after the kit is assembled. It's best to defer this operation until after the rest of the Setup and Adjustment process has been performed.

## What you'll need to complete the assembly

- DVM (digital voltmeter)
- Small flat blade or phillips screwdriver

## Procedure to set the bias current is:

- Measure the voltage between the **Current** and **Vcc** testpoints as shown in the figure below. There is a 1 ohm resistor between the testpoints, so the voltage between the testpoints corresponds to the current flowing through the resistor (10 mV equals 10 mA). The DVM positive/red lead goes to the Vcc testpoint. The DVM negative/black lead goes to the Current testpoint.
- The bias current is different for each band. Find the appropriate bias current from Table below.
- Start up the transmitter and wait until it's transmitting (LED is on).
- Set the bias current using R11 (see figure below) using a small blade screwdriver (clockwise increases the current). For example, the bias voltage for an 80m WSPR transmitter would be set to 60 mV, which corresponds to 60 mA.
- **Do not let the bias current exceed 70 mA (70 mV on the DVM).**

Band	Bias Current
160m	60 mA
80m	60 mA
40m	60 mA
30m	60 mA
20m	60 mA
17m/15m	60 mA
12m,10m	60 mA

# TAPR Versatile WSPR Bias Current Adjustment

